


Ask About Our Build-to-Print and Custom Capabilities

# **Bi-Convex Spherical Lenses**

OEM

Bi-convex or symmetric-convex lenses have two convex surfaces with identical radii. They are recommended for virtual imaging of real objects and for positive conjugate ratios from approximately 0.2 to 5 (values are wavelength sensitive). Due to the symmetry, aberrations such as coma, distortion, and chromatic aberration almost exactly cancel out at unit conjugate ratio. Aberrations increase as conjugate ratios depart from unity.

- Bi-convex symmetric-convex lenses have positive focal lengths and form both real and virtual images
- They are available in both BK7 glass, synthetic fused silica, and magnesium fluoride
- Refer to CVI Melles Griot standard size codes, radii of curvature and radii tolerance charts



#### **Bi-convex lens**

#### Standard BK7 Bi-Convex Lenses

f φ PART NUMBER  $f_{b}$  $t_{c}$  $t_{\rm e}$ FORMER‡ **REPLACED BY** (mm) (mm) f/# (mm) (mm) (mm) (mm) 4.5 5.0 0.9 3.8 2.0 0.4 4.3 01 LDX 401 LDX-5.0-4.3-C 01 LDX 001 LDX-5.0-6.7-C 7.0 5.0 1.4 5.9 3.0 2.0 6.7 6.0 1.3 6.9 3.2 2.0 7.7 01 LDX 003 LDX-6.0-7.7-C 8.0 10.0 5.0 2.0 9.1 2.6 2.0 9.9 01 LDX 005 LDX-5.0-9.9-C 10.0 10.0 1.0 8.3 4.8 1.9 9.5 01 LDX 009 LDX-10.0-9.5-C 12.5 7.3 7.1 2.0 9.0 LDX-12.5-9.0-C 10.0 0.8 01 LDX 301 10.5 5.5 LDX-12.5-11.9-C 12.5 12.5 1.0 2.0 11.9 01 LDX 303 12.7 6.3 2.0 2.8 2.0 01 LDX 013 LDX-6.3-12.7-C 11.7 12.7 14.2 12.5 1.1 12.4 5.0 2.0 13.8 01 LDX 015 LDX-12.5-13.8-C 2.0 14.0 2.9 2.0 15.0 01 LDX 017 LDX-7.5-15.0-C

‡ Former Melles Griot part number is replaced by new CVI Melles Griot part number

# **BK7 Bi-Convex Lenses**

#### Standard BK7 Bi-Convex Lenses

Other CVI Melles Griot AR coatings also available (488-515, 532, 532/1064, 543, 633, 694, 755, 780, 800, 830, 1047, 1053, 1064, 1310, 1550 and 2100 nm)

#### **SPECIFICATIONS:**

Paraxial Focal Length  $f \pm 2\%$ , (400 series  $\pm 4\%$ ) Clear Aperture (CA) 90% of central diameter **Optical Material** BK7 **Center Thickness**  $t_c \pm 0.2 \text{ mm}$ Centration ≤3 arc minutes Diameter  $\phi + 0/ - 0.10 \text{ mm} (+0/ - 0.15 \text{ mm})$ for  $\phi \ge 75$  mm) **Surface Quality** 60-40 scratch and dig **Edge Characteristics** 0.25-0.50-mm bevel

**Build Your Own** 

LDX-10.0-9.5.3-C — 425-675

**Lens Part Number** 

Wavelength of AR Coating (nm)

SLMF-400-700 670-1064 425-675 1050-1600

(continued)



## **Standard BK7 Bi-Convex Lenses** (continued)

f	φ		$f_{b}$	t <sub>c</sub>	$t_{e}$	r	PART	PART NUMBER	
(mm)	(mm)	f/#	(mm)	(mm)	(mm)	(mm)	FORMER‡	REPLACED BY	
15.0	12.5	1.2	13.3	4.8	2.0	14.7	01 LDX 305	LDX-12.5-14.7-C	
15.0	14.5	1.0	12.9	5.9	2.0	14.5	01 LDX 019	LDX-14.5-14.5-C	
18.0	13.0	1.4	16.5	4.4	2.0	17.9	01 LDX 023	LDX-13.0-17.9-C	
20.0	12.5	1.6	18.6	4.0	2.0	20.0	01 LDX 307	LDX-12.5-20.0-C	
20.0	15.0	1.3	18.3	4.9	2.0	19.9	01 LDX 025	LDX-15.0-19.9-C	
20.0	21.0	1.0	17.1	8.2	2.0	19.2	01 LDX 027	LDX-21.0-19.2-C	
20.0	25.0	0.8	15.6	11.8	2.1	18.5	01 LDX 327	LDX-25.0-18.5-C	
22.0	20.0	1.1	19.6	6.9	2.0	21.6	01 LDX 029	LDX-20.0-21.6-C	
25.0	12.5	2.0	23.8	3.6	2.0	25.3	01 LDX 309	LDX-12.5-25.3-C	
25.0	22.4	1.1	22.5	7.3	1.9	24.6	01 LDX 035	LDX-22.4-24.6-C	
25.0	25.0	1.0	21.9	8.9	2.0	24.3	01 LDX 329	LDX-25.0-24.3-C	
25.4	20.0	1.3	23.3	6.1	2.0	25.3	01 LDX 041	LDX-20.0-25.3-C	
25.4	25.4	1.0	22.2	9.0	2.0	24.7	01 LDX 043	LDX-25.4-24.7-C	
28.6	12.7	2.3	27.5	3.4	2.0	29.1	01 LDX 049	LDX-12.7-29.1-C	
30.0	12.5	2.4	28.9	3.3	2.0	30.5	01 LDX 311	LDX-12.5-30.5-C	
30.0	22.4	1.3	27.8	6.3	2.0	30.0	01 LDX 055	LDX-22.4-30.0-C	
30.0	30.0	1.0	26.4	10.3	2.0	29.3	01 LDX 057	LDX-30.0-29.3-C	
31.7	25.4	1.2	29.2	7.3	2.0	31.6	01 LDX 061	LDX-25.4-31.6-C	
31.7	35.0	0.9	27.1	12.9	1.9	30.5	01 LDX 063	LDX-35.0-30.5-C	
33.0	10.0	3.3	32.1	2.7	2.0	33.8	01 LDX 065	LDX-10.0-33.8-C	
35.0	19.5	1.8	33.4	4.7	2.0	35.5	01 LDX 067	LDX-19.5-35.5-C	
38.1	38.1	1.0	33.8	12.4	1.9	37.3	01 LDX 079	LDX-38.1-37.3-C	
40.0	12.5	3.2	39.0	3.0	2.0	41.0	01 LDX 313	LDX-12.5-41.0-C	
40.0	25.0	1.6	38.0	5.9	1.9	40.5	01 LDX 085	LDX-25.0-40.5-C	
40.0	50.0	0.8	31.9	22.2	2.9	37.3	01 LDX 365	LDX-50.0-37.3-C	
50.0	12.5	4.0	49.1	2.8 5.1	2.0	51.4	01 LDX 315	LDX-12.5-51.4-C	
50.0 50.0	25.0 30.0	2.0 1.7	48.3 47.8	6.5	2.0 2.0	51.0 50.7	01 LDX 103 01 LDX 104	LDX-25.0-51.0-C LDX-30.0-50.7-C	
50.0	31.0	1.7	47.8 47.7	6.8	1.9	50.7	01 LDX 104	LDX-30.0-30.7-C	
50.0	42.0	1.0	46.2	11.2	1.9	49.9	01 LDX 103	LDX-31.0-30.7-C LDX-42.0-49.9-C	
50.0	50.0	1.0	44.5	15.8	2.1	49.0	01 LDX 367	LDX-42.0-49.9-C	
50.8	60.0	0.8	42.3	23.7	2.8	48.3	01 LDX 117	LDX-60.0-48.3-C	
54.0	32.0	1.7	51.7	6.7	1.9	54.9	01 LDX 117	LDX-32.0-54.9-C	
60.0	50.0	1.2	55.6	12.9	2.0	60.0	01 LDX 123	LDX-50.0-60.0-C	
62.5	25.0	2.5	61.0	4.5	2.0	64.1	01 LDX 333	LDX-25.0-64.1-C	
63.5	50.0	1.3	59.0	13.2	3.0	63.5	01 LDX 127	LDX-50.0-63.5-C	
65.0	35.0	1.9	62.8	6.7	2.0	66.3	01 LDX 129	LDX-35.0-66.3-C	
70.0	30.0	2.3	68.3	5.2	2.0	71.7	01 LDX 135	LDX-30.0-71.7-C	
75.0	12.5	6.0	74.2	2.5	2.0	77.4	01 LDX 317	LDX-12.5-77.4-C	
75.0	25.0	3.0	73.7	4.0	2.0	77.1	01 LDX 141	LDX-25.0-77.1-C	
75.0	50.0	1.5	71.1	11.5	3.0	75.8	01 LDX 369	LDX-50.0-75.8-C	
76.2	50.8	1.5	72.3	11.5	2.9	77.0	01 LDX 145	LDX-50.8-77.0-C	
80.0	22.4	3.6	78.8	3.5	2.0	82.4	01 LDX 149	LDX-22.4-82.4-C	
80.0	47.0	1.7	77.0	8.9	2.0	81.4	01 LDX 157	LDX-47.0-81.4-C	
88.9	25.4	3.5	87.6	3.8	2.0	91.6	01 LDX 161	LDX-25.4-91.6-C	
t Formar Mall	os Criot part pum	har is raplaced by	new CVI Melles G	riot part pumbo				(continued)	

‡ Former Melles Griot part number is replaced by new CVI Melles Griot part number

(continued)

### **Standard BK7 Bi-Convex Lenses** (continued)

f	φ		$f_{b}$	$t_{c}$	$t_{e}$	r	PA	PART NUMBER	
(mm)	(mm)	f/#	(mm)	(mm)	(mm)	(mm)	FORMER‡	REPLACED BY	
100.0	12.5	8.0	99.2	2.4	2.0	103.3	01 LDX 319	LDX-12.5-103.3-C	
100.0	22.4	4.5	98.9	3.2	2.0	103.2	01 LDX 167	LDX-22.4-103.2-C	
100.0	25.0	4.0	98.8	3.5	2.0	103.1	01 LDX 335	LDX-25.0-103.1-C	
100.0	30.0	3.3	98.6	4.2	2.0	103.0	01 LDX 168	LDX-30.0-103.0-C	
100.0	50.0	2.0	97.3	8.2	2.0	102.3	01 LDX 171	LDX-50.0-102.3-C	
101.6	50.8	2.0	98.5	9.3	3.0	103.8	01 LDX 179	LDX-50.8-103.8-C	
125.0	12.5	10.0	124.2	2.3	2.0	129.3	01 LDX 321	LDX-12.5-129.3-C	
125.0	25.0	5.0	123.9	3.2	2.0	129.1	01 LDX 185	LDX-25.0-129.1-C	
127.0	50.8	2.5	124.3	8.0	3.0	130.4	01 LDX 189	LDX-50.8-130.4-C	
150.0	25.0	6.0	149.0	3.0	2.0	155.1	01 LDX 337	LDX-25.0-155.1-C	
150.0	30.0	5.0	148.8	3.5	2.0	155.0	01 LDX 202	LDX-30.0-155.0-C	
150.0	50.0	3.0	148.0	6.1	2.0	154.6	01 LDX 205	LDX-50.0-154.6-C	
150.0	75.0	2.0	145.9	12.2	2.9	153.5	01 LDX 209	LDX-75.0-153.5-C	
150.0	95.0	1.6	144.0	18.0	2.8	152.5	01 LDX 211	LDX-95.0-152.5-C	
175.0	12.5	14.0	174.3	2.2	2.0	181.2	01 LDX 323	LDX-12.5-181.2-C	
175.0	25.0	7.0	174.1	2.9	2.0	181.1	01 LDX 339	LDX-25.0-181.1-C	
200.0	25.0	8.0	199.1	2.8	2.0	207.0	01 LDX 341	LDX-25.0-207.0-C	
200.0	30.0	6.7	199.0	3.1	2.0	207.0	01 LDX 218	LDX-30.0-207.0-C	
200.0	50.0	4.0	198.3	5.0	2.0	206.6	01 LDX 222	LDX-50.0-206.6-C	
200.0	100.0	2.0	194.6	16.3	3.9	204.7	01 LDX 223	LDX-100.0-204.7-C	
250.0	12.5	20.0	249.3	2.2	2.0	259.0	01 LDX 325	LDX-12.5-259.0-C	
250.0	25.0	10.0	249.1	2.6	2.0	258.9	01 LDX 343	LDX-25.0-258.9-C	
250.0	42.0	6.0	248.8	3.7	2.0	258.7	01 LDX 225	LDX-42.0-258.7-C	
250.0	50.0	5.0	248.2	5.4	3.0	258.4	01 LDX 371	LDX-50.0-258.4-C	
250.0	100.0	2.5	245.4	13.7	3.9	257.0	01 LDX 235	LDX-100.0-257.0-C	
300.0	25.0	12.0	299.2	2.5	2.0	310.8	01 LDX 345	LDX-25.0-310.8-C	
300.0	42.0	7.1	298.9	3.4	2.0	310.7	01 LDX 237	LDX-42.0-310.7-C	
325.0	50.0	6.5	323.4	4.9	3.0	336.3	01 LDX 373	LDX-50.0-336.3-C	
350.0	25.0	14.0	349.2	2.4	2.0	362.7	01 LDX 347	LDX-25.0-362.7-C	
400.0	25.0	16.0	399.2	2.4	2.0	414.6	01 LDX 349	LDX-25.0-414.6-C	
400.0	42.0	9.5	399.0	3.1	2.0	414.4	01 LDX 243	LDX-42.0-414.4-C	
500.0	25.0	20.0	499.2	2.3	2.0	518.3	01 LDX 351	LDX-25.0-518.3-C	
500.0	30.0	16.7	499.2	2.4	2.0	518.3	01 LDX 245	LDX-30.0-518.3-C	
500.0	50.0	10.0	498.9	3.2	2.0	518.2	01 LDX 248	LDX-50.0-518.2-C	
600.0	25.0	24.0	599.3	2.3	2.0	622.1	01 LDX 353	LDX-25.0-622.1-C	
625.0	50.0	12.5	623.7	4.0	3.0	647.7	01 LDX 375	LDX-50.0-647.7-C	
700.0	25.0	28.0	699.3	2.2	2.0	725.8	01 LDX 355	LDX-25.0-725.8-C	
750.0	50.0	15.0	748.7	3.8	3.0	777.4	01 LDX 377	LDX-50.0-777.4-C	
800.0	25.0	32.0	799.3	2.2	2.0	829.6	01 LDX 357	LDX-25.0-829.6-C	
1000.0	25.0	40.0	999.3	2.2	2.0	1037.1	01 LDX 359	LDX-25.0-1037.1-C	
1000.0	30.0	33.3	999.3	2.2	2.0	1037.1	01 LDX 258	LDX-30.0-1037.1-C	
1000.0	50.0	20.0	999.1	2.6	2.0	1037.0	01 LDX 262	LDX-50.0-1037.0-C	
1500.0	25.0	60.0	1499.3	2.1	2.0	1555.8	01 LDX 361	LDX-25.0-1555.8-C	
1500.0	50.0	30.0	1498.9	3.4	3.0	1555.6	01 LDX 379	LDX-50.0-1555.6-C	
2000.0	25.0	80.0	1999.3	2.1	2.0	2074.5	01 LDX 363	LDX-25.0-2074.5-C	
2000.0	42.0	47.6	1999.3	2.2	2.0	2074.5	01 LDX 263	LDX-42.0-2074.5-C	
2000.0	50.0	40.0	1998.9	3.3	3.0	2074.3	01 LDX 381	LDX-50.0-2074.3-C	

<sup>‡</sup> Former Melles Griot part number is replaced by new CVI Melles Griot part number




Beamsplitters



# **Bi-Concave Spherical Lenses**

Bi-Concave or symmetric-concave lenses have a negative focal length and two concave surfaces with identical radii. Bi-concave lenses can be found in laser beam expanders, optical character readers, viewers, and projection systems.

- Bi-concave lenses diverge collimated incident light
- They form virtual images which can be seen through the lens
- Refer to CVI Melles Griot standard size codes, radii of curvature and radii tolerance charts



Symmetric-concave lens

## **BK7 Bi-Concave Lenses**

## **Standard BK7 Bi-Concave Lenses**

Other CVI Melles Griot AR coatings also available (488-515, 532, 532/1064, 543, 633, 694, 755, 780, 800, 830, 1047, 1053, 1064, 1310, 1550 and 2100 nm)

#### **SPECIFICATIONS:**

Paraxial Focal Length	$f\pm 2\%$
Design Wavelength	546.1 nm
Clear Aperture (CA)	$\phi - 2\Delta$
Optical Material	BK7
Center Thickness	$t_{\rm c} \pm 0.2  {\rm mm}$
Centration	≤ 3 arc minutes
Diameter	$\phi$ + 0/ - 0.1 mm ( + 0/ - 0.15 mm
	for $\phi \ge 75$ mm)
Surface Quality	60-40 scratch and dig
<b>Edge Characteristics</b>	0.05–0.20-mm bevel
Flat Annulus Width (Δ)	0.2 mm for $\phi \le 40$ mm;
	0.4 mm for $\phi$ >40 mm (+0/-70%)

## **Build Your Own**

LDK-12.0-12.8-C — 425-675

#### **Lens Part Number**

# Wavelength of AR Coating (nm)

SLMF-400-700 670-1064 425-675 1050-1600

#### **Standard BK7 Bi-Concave Lenses**

CVI Melles Griot www.cvimellesgriot.com

f	$\phi$		$f_{b}$	$t_{c}$	$t_{e}$	r	PART	PART NUMBER	
(mm)	(mm)	f/#	(mm)	(mm)	(mm)	(mm)	FORMER‡	REPLACED BY	
-5.0	5.0	-1.1	- 5.6	2.0	3.0	5.5	01 LDK 001	LDK-5.0-5.5-C	
-8.0	6.0	-1.4	-8.6	2.0	2.9	8.6	01 LDK 003	LDK-6.0-8.6-C	
-12.0	12.0	<b>-1.0</b>	<b>-12.6</b>	2.0	4.8	12.8	01 LDK 005	LDK-12.0-12.8-C	
<b>-12.5</b>	12.5	-1.0	<b>-13.2</b>	2.0	4.9	13.3	01 LDK 105	LDK-12.5-13.3-C	
<b>- 15.0</b>	12.5	-1.2	<b>–</b> 15.7	2.0	4.4	15.9	01 LDK 107	LDK-12.5-15.9-C	

‡ Former Melles Griot part number is replaced by new CVI Melles Griot part number CVI Melles Griot can reduce (edge) diameters of lenses to meet your requirements. Contact us for details. (continued)

4.45

LDK-C

## **Standard BK7 Bi-Concave Lenses** (continued)

f	φ		$f_{b}$	$t_{c}$	$t_{e}$	r	PART	PART NUMBER	
(mm)	(mm)	f/#	(mm)	(mm)	(mm)	(mm)	FORMER‡	REPLACED BY	
-20.0	12.5	-1.7	-20.7	2.0	3.8	21.1	01 LDK 109	LDK-12.5-21.1-C	
-20.0	20.0	<b>-1.0</b>	-20.6	2.0	6.8	21.1	01 LDK 007	LDK-20.0-21.1-C	
<b>- 25.0</b>	12.5	<b>-2.1</b>	<b>-25.7</b>	2.0	3.4	26.3	01 LDK 111	LDK-12.5-26.3-C	
<b>- 25.0</b>	25.0	<b>-1.0</b>	<b>-25.7</b>	2.0	8.1	26.3	01 LDK 009	LDK-25.0-26.3-C	
- 30.0	12.5	<b>- 2.5</b>	-30.7	2.0	3.2	31.5	01 LDK 113	LDK-12.5-31.5-C	
- 30.0	13.0	<b>-2.4</b>	-30.7	2.0	3.3	31.5	01 LDK 012	LDK-13.0-31.5-C	
-30.0	20.0	<b>–</b> 1.5	-30.7	2.0	5.1	31.5	01 LDK 013	LDK-20.0-31.5-C	
- 30.0	30.0	-1.0	-30.7	2.0	9.4	31.5	01 LDK 015	LDK-30.0-31.5-C	
- 35.0	20.0	-1.8	-35.7	2.0	4.7	36.6	01 LDK 016	LDK-20.0-36.6-C	
<b>- 37.5</b>	25.0	<b>- 1.5</b>	-38.2	2.0	6.0	39.2	01 LDK 115	LDK-25.0-39.2-C	
-40.0	12.5	- 3.3	-40.7	2.0	2.9	41.8	01 LDK 117	LDK-12.5-41.8-C	
-40.0	22.4	-1.8	-40.7	2.0	4.9	41.8	01 LDK 017	LDK-22.4-41.8-C	
- 50.0	12.5	<b>-4.1</b>	-50.7	2.0	2.7	52.2	01 LDK 119	LDK-12.5-52.2-C	
- 50.0	25.0	-2.0	-50.7	2.0	4.9	52.2	01 LDK 121	LDK-25.0-52.2-C	
- 50.0	30.0	<b>-1.7</b>	-50.7	2.0	6.3	52.2	01 LDK 018	LDK-30.0-52.2-C	
- 50.0	42.0	-1.2	-50.7	2.0	10.5	52.2	01 LDK 021	LDK-42.0-52.2-C	
-50.0	50.0	<b>-1.2</b>	-50.7	2.0	14.3	52.2	01 LDK 122	LDK-50.0-52.2-C	
<b>-62.5</b>	25.0	<b>-2.5</b>	-63.2	2.0	4.3	65.2	01 LDK 123	LDK-25.0-65.2-C	
<b>-70.0</b>	20.0	-3.6	-70.7	2.0	3.3	73.0	01 LDK 023	LDK-20.0-73.0-C	
<b>- 75.0</b>	12.5	<b>-6.2</b>	<b>-75.7</b>	2.0	2.5	78.1	01 LDK 125	LDK-12.5-78.1-C	
<b>-75.0</b>	25.0	-3.0	<b>–</b> 75.7	2.0	3.9	78.1	01 LDK 127	LDK-25.0-78.1-C	
<b>-75.0</b>	50.0	<b>–</b> 1.5	<b>–</b> 75.7	2.0	9.9	78.1	01 LDK 129	LDK-50.0-78.1-C	
-100.0	12.5	-8.3	- 100.7	2.0	2.4	104.1	01 LDK 131	LDK-12.5-104.1-C	
-100.0	25.0	<b>-4.1</b>	- 100.7	2.0	3.5	104.1	01 LDK 133	LDK-25.0-104.1-C	
-100.0	30.0	-3.4	- 100.7	2.0	4.1	104.1	01 LDK 024	LDK-30.0-104.1-C	
-100.0	50.0	<b>-2.0</b>	- 100.7	2.0	7.9	104.1	01 LDK 026	LDK-50.0-104.1-C	
-125.0	12.5	-10.3	<b>– 125.7</b>	2.0	2.3	130.0	01 LDK 135	LDK-12.5-130.0-C	
-125.0	25.0	<b>-</b> 5.1	<b>– 125.7</b>	2.0	3.2	130.0	01 LDK 137	LDK-25.0-130.0-C	
-150.0	22.4	-6.8	<b>– 150.7</b>	2.0	2.8	156.0	01 LDK 027	LDK-22.4-156.0-C	
-150.0	25.0	<b>-6.1</b>	<b>– 150.7</b>	2.0	3.0	156.0	01 LDK 139	LDK-25.0-156.0-C	
-150.0	50.0	-3.0	<b>–</b> 150.7	2.0	5.9	156.0	01 LDK 031	LDK-50.0-156.0-C	
<b>-175.0</b>	12.5	<b>- 14.5</b>	<b>–</b> 175.7	2.0	2.2	181.9	01 LDK 141	LDK-12.5-181.9-C	
<b>-175.0</b>	25.0	<b>-</b> 7.1	<b>–</b> 175.7	2.0	2.8	181.9	01 LDK 143	LDK-25.0-181.9-C	
-200.0	25.0	<b>-8.1</b>	- 200.7	2.0	2.7	207.8	01 LDK 145	LDK-25.0-207.8-C	
-200.0	30.0	-6.8	- 200.7	2.0	3.1	207.8	01 LDK 034	LDK-30.0-207.8-C	
-250.0	12.5	<b>- 20.7</b>	<b>–</b> 250.7	2.0	2.1	259.7	01 LDK 147	LDK-12.5-259.7-C	
-250.0	25.0	-10.2	<b>–</b> 250.7	2.0	2.6	259.7	01 LDK 149	LDK-25.0-259.7-C	
-250.0	50.0	- 5.1	<b>–</b> 250.7	2.0	4.9	259.7	01 LDK 036	LDK-50.0-259.7-C	
-300.0	25.0	<b>-12.2</b>	- 300.7	2.0	2.5	311.6	01 LDK 151	LDK-25.0-311.6-C	
-300.0	50.0	-6.1	- 300.7	2.0	3.9	311.6	01 LDK 153	LDK-50.0-311.6-C	
-500.0	42.0	<b>-12.1</b>	<b>-</b> 500.7	2.0	2.8	519.1	01 LDK 041	LDK-42.0-519.1-C	
-600.0	50.0	<b>–</b> 12.2	<b>-</b> 600.7	2.0	3.0	622.9	01 LDK 045	LDK-50.0-622.9-C	

‡ Former Melles Griot part number is replaced by new CVI Melles Griot part number

CVI Melles Griot can reduce (edge) diameters of lenses to meet your requirements. Contact us for details.